## CAPRIMK2 & MK3

## BODYSIDE

M1S1 - R/H Outer Sill

M1S2 - L/H Outer Sill

M1S3 - R/H A Post Repair

M1S4 - L/H A Post Repair

M1S5 - R/H Inner Post Repair

M1S6 - L/H Inner Post Repair

M1S9 - R/H Inner Wheelhouse

M1S10 - L/H Inner Wheelhouse

M1S27 - R/H A Post Lower

M1S28 - L/H A Post Lower

M2S1 - Rear Panel Skin

M2S2 - Rear Panel Lower

M2S3 - R/H Corner Extension

M2S4 - L/H Corner Extension

M2S7 - R/H Rear Lower Corner

M2S8 - L/H Rear Lower Corner

M2S9 - R/H Arch and Corner

m203 II/II Alon and outlier

M2S10 - L/H Arch and Corner

M2S11 - R/H Rear Wing

M2S12 - L/H Rear Wing

M2S13 - R/H Outer Wheelhouse

M2S14 - L/H Outer Wheelhouse

M2S17 - R/H Door Skin

M2S18 - L/H Door Skin

M2S19 - R/H Inner Corner

M2S20 - L/H Inner Corner

M2S21 - Tailgate Repair

M2S22 - Bonnet

M2S25 - R/H Door Repair

M2S26 - L/H Door Repair

M2S27 - R/H Rear Arch and Corner

M2S28 - L/H Rear Arch and Corner

M3S1 - Rear Panel

## FLOOR

M2F3 - R/H Inner Sill

M2F4 - L/H Inner Sill

M1F1H - R/H Half Floor

M1F2H - L/H Half Floor

M1F9 - R/H Member Reinforcement

M1F10 - L/H Member Reinforcement

M1F13 - R/H Front Spring Hanger

M1F 14 - L/H Front Spring Hanger

M1F17A - R/H Inner Sill (Without Attachments)

M1F18A - L/H Inner Sill (Without Attachments)

M1F20 - R/H Rear Spring Hanger

M1F21 - L/H Rear Spring Hanger

M2F13 - R/H Member (Minus Hanger)

M2F14 - L/H Member (Minus Hanger)

M2F15 - R/H Boot Side

M2F16 - L/H Boot Side

M2F17 - Boot Floor





## ENGINE

M1E13 - Inner Wing Upright Supports (Pair) M1E13A - Inner Wing Reinforcements (Pair)

M1E14 - Inner Wing Pan

M1E31 - Centre Chassis Member M1E32 - Centre Chassis Member

M1E33 - Outrigger / Reinforcement

M1E38 - Bulkhead

M2E1 - R/H Mk2 Front Wing M2E2 - L/H Mk2 Front Wing M2E3 - R/H Inner Wing M2E4 - L/H Inner Wing

M2E5 - R/H Full Length Top Plate

M2E6 - L/H Full Length Top Plate

M2E7 - R/H Member M2E8 - L/H Member M2E11 - Crossmember M2E12 - Closing Panel M2E13 - Front Valance M2E15 - Slam Panel

M2E16 - R/H Radiator Mount M2E17- L/H Radiator Mount M2E18 - R/H Headlamp Bowl M2E19 - L/H Headlamp Bowl M2E20 - Battery Tray M2E21 - Tray Support M2E22F - Full Scuttle M2E22R - R/H Scuttle End M2E22L - L/H Scuttle End

M2S25 - L/H Bulkhead Top Repair

M2S28 - Bonnet Repair Top M2S29 - Bonnet Repair Unde

M2S29 - Bonnet Repair Underneath M2E30 - R/H Top Reinforcement M2E31 - L/H Top Reinforcement M2E32 - R/H Pan Side Reinforcement M2E33 - L/H Pan Side Reinforcement

M2E34 - R/H Splash Guard M2E34A - L/H Splash Guard

**M2E35 - Atlas Axle Diff Cover Plate** 

M3E1 - R/H Mk3 Front Wing M3E2 - L/H Mk3 Front Wing

M3E1-K - R/H Mk3 Front Wing Pattern M3E2-K - L/H Mk3 Front Wing Pattern

M3E3 - R/H Inner Wing M3E4 - L/H Inner Wing M3E13 - Front Valance

M3E21 - Tray Support (2.8 Injection Only)



